



First Choice Group

SPARE PARTS DIAGRAM FOR

winterhalter

Dish/Glass Washer

UC-M

UC-L

UC-XL


First Choice Group
Blakeney Way, Kingswood Lakeside
Cannock, Staffs, WS11 8LD
TEL: 01543 577778 FAX: 01543504141
Email: enquires@firstchoice-cs.co.uk
Web: www.firstchoice-cs.co.uk

Spare parts list

UC-M, UC-L, UC-XL

Contents


Water inlet and tank heating	Page 1 - 2
Water softener	Page 3 - 4
Water drain, Mediamat Cyclo	Page 5 - 6
Circulating pump	Page 7 - 8
Wash + rinse; bottom	Page 9 - 10
Wash + rinse; top	Page 11 - 12
Boiler	Page 13 - 16
Dosage	Page 17 - 18
Casing	Page 19 - 20
Cover plate, electrical parts	Page 21 - 22
Door	Page 23 - 24
Energy (Option)	Page 25 - 26
Hoses	Page 27 - 28



UC-M, UC-L, UC-XL

Water inlet and tank heating

Item.	Designation	Parts no.:	Pc.	Notes
1	Kit airflow preventer type "BPD"	30000128		
1.1	Nut; D26,2 X 8, SW32	60004612		
1.2	O-ring; 25,7 X 3	27 07 097		
2	Kit backflow preventer type "Air Gap"	30000127		
2.1	Nut; D26,2 X 8, SW32	60004612		
2.2	O-ring; 25,7 X 3	27 07 097		
2.3	Wire hose clamp; D14,4 X 15,1	28 02 344		
2.4	Locking cap; DN10 X 2,0 X 19	60004630		
3	Moulded hose; DN10 X 3,5 X 461	60004642		
4	Dirt trap; 150 µM	80002153		
4.1	Gasket; D16 X D24 X 3,0	80002241	3	
4.2	Strainer; D27 X 67 X 150µM	80002728		
4.3	Double nipple; G 3/4" X 40; SW30	80002167		
5	Water supply hose; DN13 X 3,5; 2500	40 02 060		
5.1	Gasket; D16 X D24 X 3,0	80002241	2	
6	Raised head screw; M4 X 8	20 10 310	2	
7	Solenoid valve flow restrictor 4l; 230-240V 50/60HZ RAST5	31 06 250		
7	Solenoid valve flow restrictor 4l; 200-240V/50-60HZ/+/-10%	31 06 251		Japan; Australia
7	Solenoid valve flow restrictor 3l; 200-240V/50-60HZ/+/-10%	31 06 211		Energy
7.1	Solenoid valve filter	31 06 186		
8	Wire hose clamp; D17,3 X 1,8	28 02 353		
9	Kit air chamber	30000114		
9.1	Nut; D26,2 X 8, SW32	60004612		
9.2	O-ring; 25,7 X 3	27 07 097		
10	Kit thermal sensor	30000126		
10.1	Heat conducting foil; 24 X 17 X 0,25MM	31 14 096		
10.2	Ratchet nut; M5	21 01 310		
12	Wire hose clamp; D9,1 X 1	28 02 349		
13	Hose; DN5 X 1,5	40 01 024		930 mm; "By-the-metre" goods
14	Kit high power heating cartridge 1.8KW	30000122		
14.1	O-ring; 34 X 6,0	27 07 092		
15	Kit high power heating cartridge 2.5KW	30000123		UC-x Cool
15.1	O-ring; 34 X 6,0	27 07 092		
16	Pressure transmitter; 0-30MBAR;5VDC/0,5-3,5V	31 26 044		
17				See page 27-28
18	Moulded hose; DN13 X 2,0	60004668		
19	Moulded hose; DN10 X DN13 X 2,0	60004664		




60005006-00

UC-M, UC-L, UC-XL

Water softener

Item.	Designation	Parts no.:	Pc.	Notes
1	Water softener kit; 220-240V; 50/60HZ	83000420		
1.1	Cover, complete, with seal	83000407		
1.2	Lock nut; S54 X 4; D56	60003001		
1.3	O-ring; 54 X 5	27 07 065		
1.4	Dry reed contact lack of salt	83000408		
1.5	Repair kit regeneration valve; 220-240V,50/60HZ	83000402		
1.6	Repair kit reversing valve; 220-240V,50/60HZ	83000460		
2	Water softener kit; 200-210V; 50/60HZ	83000421		
2.1	Cover, complete, with seal	83000407		
2.2	Lock nut; S54 X 4; D56	60003001		
2.3	O-ring; 54 X 5	27 07 065		
2.4	Dry reed contact lack of salt	83000408		
2.5	Repair kit regeneration valve; 200-210V,50/60HZ	83000463		
2.6	Repair kit reversing valve; 200-210V,50/60HZ	83000467		
3	Double hex ring spanner; SW61,5	60003376		
4	Wire hose clamp; D16,4 X 1,8	28 02 352	2	
5	Wire hose clamp; D14,4 X 15,1	28 02 344	2	
6	Moulded hose; DN10 X DN11 X 2,0	60004671		
7	Moulded hose; DN10 X 2,0	60004683		UC-M Energy
8	Moulded hose; DN10 X 2,0	60004672		UC-L Energy, UC-XL Energy
9	Filling funnel	35 02 013		
10	Moulded hose; DN10 X 2,0	60004711		
11	Hose; DN10 X 2,0	40 01 050		800 mm; "By-the-metre" goods
12	Hose; DN10 X 2,0	40 01 050		650 mm; "By-the-metre" goods




60005007-00

UC-M, UC-L, UC-XL

Water drain, Mediamat Cyclo

Item.	Designation	Parts no.:	Pc.	Notes
1	FILTER CYLINDER	60004463		
2	Flat filter; 1,0 X 238 X 540,95	60004357		
3	Kit Mediamat	30000113		
3.1	Nut; D26,2 X 8, SW32	60004612		
3.2	O-ring; 25,7 X 3	27 07 097		
4	Wire hose clamp; D17,3 X 1,8	28 02 353		
5	Hose; DN10,5 X 3,0; 139	60004628		
6	Moulded hose; DN12,5 X 2,00	60004620		
7	Drain pump; 220-240V/50HZ	31 02 480		
7	Drain pump; 200V/50HZ;220-240V/60H	31 02 493		
7	Drain pump; 200V/60HZ	31 02 495		
8	FILTER BOTTOM; D139 X 63,5	60004466		
9	Drain hose; 1500 LG	60003738		
10	Hose clamp; D20-30 X 12	28 02 109		
11	Double nipple; D21,8 X 55, D20,8	60004609		
12	Wire hose clamp; D24,2 X 2,2	28 02 358		
13	Shaped hose; DN18 X DN22; 814	60003281		UC-M
14	Reinforced hose; DN19 X 2,5	40 01 046		460 mm; "By-the-metre" goods
15	Deaeration kit	60003514		
15.1	Ball; D14	28 01 508		
15.2	O-ring; 24 X 3,0	27 07 087		
15.3	Round cap; D11 X 20	35 03 029		
16	Moulded hose; DN10 X 2,0	60004711		from built-in water softener
17	Wire hose clamp; D26,8 X 2,5	28 02 360		
18	Shaped hose; DN18 X DN22 X 2,25	60004004		UC-L; UC-XL




60005008-00

UC-M, UC-L, UC-XL

Circulating pump

Item.	Designation	Parts no.:	Pc.	Notes
1	KIT CIRCULATING PUMP	30000167		
1.1	Impeller with sealings kit; D92	60003592		
1.2	Sealing for pump system kit	60003591		
2	Adapter bracket	60004710		
3	PT screw; KB 50 X 16	20 17 007	2	
4	Cylinder head screw; M5 X 20; 8,8	20 09 337	3	
5	Serrated lock washer; A-5,3	22 02 316	3	
6	Washer; D5,3 X D10 X 1,0	22 01 305	3	
7	Kit COLLECTOR	30000169		
7.1	Sealing for pump system kit	60003591		
7.2	O-ring; 21 X 3	27 07 096		
8	SUCTION CHANNEL	60004467		
9	PT screw; KB 30 X 10	20 17 005	3	
10	KIT DIFFUSION SENSOR	30000168		
10.1	O-ring; 21 X 3	27 07 096		
11	PT screw; KB 30 X 10	20 17 005	2	
12	Pump clip	62003437		
12.1	Hexagon screw; M5 X 40; A70	20 01 329		




60005009-00

UC-M, UC-L, UC-XL

Wash + rinse; bottom

Item.	Designation	Parts no.:	Pc.	Notes
1	Wash field	60004427		
1.1	Plug	60004854	2	
2	Wire hose clamp; D21,2 X 2	28 02 355		
3	Rinse manifold	60004611		
4	MOLDED HOSE BOTTOM; DN13,5 X 3,0 X 370	60004625		
5	Wire hose clamp; D44,4 X 3,2	28 02 367		
6	Reducing hose; DN33 X DN46; 97	60004591		
7	Wire hose clamp; D56 X 3,5	28 02 371		
8	Magnetic switch; 25,5 X D5,8; 220MM LG	31 24 297		
9	KIT WATER INLET BOTTOM	30000199		
9.1	O-ring; 56 X 3,0	27 07 086		
10	Kit wash field take-up device bottom	30000112		
10.1	Seal ring; D48,4 X 52,5 X 1,6	60004430		
10.2	Lock nut bottom	60004872		
10.3	O-ring; 12,5 X 2,0	27 07 003		




60005010-00

UC-M, UC-L, UC-XL

Wash + rinse; top

Item.	Designation	Parts no.:	Pc.	Notes
1	KIT WATER INLET TOP	30000200		
1.1	FOAM RUBBER	60004500		
1.2	O-ring; 56 X 3,0	27 07 086		
2	Magnetic switch; 25,5 X D5,8; 220MM LG	31 24 297		
3	PT screw; KB 30 X 10	20 17 005		
4	Wire hose clamp; D21,2 X 2	28 02 355		
6	Wash field	60004427		
6.1	Plug	60004854	2	
7	Kit winse field take-up device top	30000111		
7.1	O-ring; 12,5 X 2,0	27 07 003		
7.2	Lock nut top	60004870		
7.3	Seal ring; D48,4 X 52,5 X 1,6	60004430		
8	Wire hose clamp; D44,4 X 3,2	28 02 367		
9	Hose; DN33 X 4,0; 225	60004843		adapt
10	Wire hose clamp; D42,9 X 3,2	28 02 366		
11	RISER	60004572		UC-M
12	RISER	60004514		UC-L; UC-XL
13	Hose; DN33 X 4,0; 225	60004843		
14	MOLDED HOSE TOP; DN13,5 X 3,0 X 605	60004644		UC-M
15	MOLDED HOSE TOP; DN13,5 X 3,0 X 700	60004624		UC-L; UC-XL




UC-M, UC-L, UC-XL

Boiler

Item.	Designation	Parts no.:	Pc.	Notes
1	Ratchet nut; M5	21 01 310		
2	Retainer; 53,62 X 104	60004493		
3	Pressure transmitter; 0-30MBAR;5VDC/0,5-3,5V	31 26 044		
4	Wire hose clamp; D9,1 X 1	28 02 349		
5	Hose; DN5 X 1,5	40 01 024		650 mm; "By-the-metre" goods
6	Moulded hose; DN13 X 2,0	60004667		
7	Moulded hose; DN10 X DN13 X 2,0	60004664		
8	Moulded hose; DN23,5 X DN26,5 X 3,5	60004573		
9	Wire hose clamp; D32,7 X 2,8	28 02 362		
10	O-ring; 10 X 2,5	27 07 030	2	
11	Housing; 62 X 121 X 139	60004821		
12	Assembly plate; 0,8 X 61,2 X 175,26	60004819		
13	PT screw; KB 30 X 10	20 17 005		
14	Contactor B7:3H 1 N/C contact; 220-255V/50-60HZ	31 04 154		
14	Contactor B7:3H 1 N/C contact; 200V/50-60HZ	31 04 171		Japan
15	UT 4-Quattro, potenial earth, double terminal; GRÜN/GELB	31 09 272		
16	UT 4-Quattro double terminal; GRAU	31 09 270	6	
17	Blue UT 4-Quattro, double terminal; BLAU	31 09 271		
18	Cover; D-UT 2,5/4-QUATTRO	31 09 279		
19	Universal fuse clip	31 09 063	2	
19.1	Securing plug	31 09 072		
20	Fine fuse, medium time lag; 250V; 4,0A; 5 X 20	31 11 123		
21	Fixed bridge; 4-pole; FB 10-8; 4-POLIG; FBS 4-6	31 09 278		
22	Kit heating element 4.9KW with fuse	30000125		
22	Kit heating element 6.5KW with fuse	30000124		Japan; Australia
22.1	Hexagonal nut; M5	21 01 203	3	
22.2	O-ring; 46 X 6,0	27 07 085		
23	Plug; D24 X D13,1 X 27	70007962		
24	Wire hose clamp; D14,4 X 15,1	28 02 344		
25	Hose; D10 X 2	40 02 034		450 mm; "By-the-metre" goods
26	Hose; DN5 X 1,5	40 01 027		510 mm; "By-the-metre" goods
27	Wire hose clamp; D17,3 X 1,8	28 02 353		
28	Kit thermal sensor	30000126		
28.1	Ratchet nut; M5	21 01 310		
28.2	Heat conducting foil; 24 X 17 X 0,25MM	31 14 096		
29	Kit boiler	30000119		
29.1	Four-lipped seal; D50,39 X 3,53	30000134		
29.2	Kit air chamber, boiler	30000116		
29.3	Ratchet nut; M5	21 01 310	4	
29.4	O-ring; 46 X 6,0	27 07 085		
30	Wire hose clamp; D35 X 3	28 02 364		


For missing items, see next page



UC-M, UC-L, UC-XL

Boiler

Item.	Designation	Parts no.:	Pc.	Notes
31	Pump 0.14kW 3/3; 220V/240V/1/50HZ	31 02 561		220V-240VN~/380V-415V3N~,50Hz
31.1	Cord; D=78 X 3; SHOR 50-55;	40 04 023		
31.2	Pump impeller; FÜR UP60/UP30 MIT 50HZ	31 02 466		
31.3	Pump housing; D=80,5MM	31 02 519		
31.4	Screw for pump housing	31 01 118	7	
31.5	Capacitor; 4 MIKRO F / 400V	31 13 171		
32	Pump 0.20kW 3/3; 200-240V/1/50-60HZ	31 02 589		220V-240VN~/380V-415V3N~,60Hz; 200V/50+60Hz
32.1	Cord; D=78 X 3; SHOR 50-55;	40 04 023		
32.2	Pump impeller, installed; FÜR UP60 MIT 60HZ	31 02 587		
32.3	Pump housing; D=80,5MM	31 02 519		
32.4	Screw for pump housing	31 01 118	7	
32.5	Capacitor; 5 MIKRO F	31 13 099		
33	Wire hose clamp; D26,8 X 2,5	28 02 360		
34	Moulded hose; DN18 X DN24 X 3,5	60004632		
35	Radio interference suppression capacitor; 0,22 MF + 2 X 22'000PF	31 13 211		
36	Hexagon screw; M5 X 16; A70	20 01 309		




60005012-00

UC-M, UC-L, UC-XL

Dosage

Item.	Designation	Parts no.:	Pc.	Notes
1	Fluidos DB "Rinse aid" kit; 115-240V/50-60HZ	31 02 598		
2	Fluidos DT "Detergent" kit; 115-240V/50-60HZ	31 02 597		
3	Wire hose clamp; D9,1 X 1	28 02 349		
4	Hose; DN5 X 1,5	40 01 027		510 mm; "By-the-metre" goods
5	Hose; DN5 X 1,5	40 01 024		370 mm; "By-the-metre" goods
6	SEPARATING PLATE RIGHT	60004534		
7	Magnetic switch; 25,5 X D5,8; 220MM LG	31 24 297		
8	Hexagon screw; M5 X 65	20 01 206	2	
9	TRANSVERSE GIRDER	60004532		
10	PT screw; KB 30 X 10	20 17 005		
11	Magnetic switch; 25,5 X D5,8; 450MM LG	31 24 296		
12	SEVICE FLAP 15; 0,8 X 305,63 X 612,6	60004485		without detergent, freshwater rinse dispenser
13	SUCTION TUBE; D6 X 1,0 X 209	60004729		
14	Ratchet nut; M5	21 01 310	2	
15	Hose; DN5 X 1,5	40 01 027		570mm; "By-the-metre" goods
16	Kit chemical container big	30000117		
16.1	FLAP BLUE; 30,2 X 32,8 X 59,8	60004540		
16.2	FLAP WHITE; 30,2 X 32,8 X 59,8	60004541		
17	SERVICE FLAP 35	60004659		
18	Housing panel Housing panel	60004814		only dosing of rinse aid or detergent
19	Housing panel Housing panel	60004657		with detergent, freshwater rinse dispenser
20	Hexagonal nut; M5 SELBSTSICHERND	21 05 302	4	
21	Washer; D5,3 X D10 X 1,0	22 01 300	4	
22	Sheet metal; 1,25 X 35 X 36	60004662	2	
23	Hose; DN5 X 1,5	40 01 024		270 mm; "By-the-metre" goods
24	Cover	60004588		
25	SEPARATING PLATE LEFT	60004533		
26	Dosing nipple set; M10 X 29; SW5	61005883		
26.1	O-ring; 10 X 2,5	27 07 030		
26.2	Wire hose clamp; D8,6 X 1	28 02 348		




60005013-00

UC-M, UC-L, UC-XL

Casing

Item.	Designation	Parts no.:	Pc.	Notes
1	Back panel	62003846		UC-M; Stainless steel
1	Back panel	62003931		UC-M; Plastic
2	Back panel	60004461		UC-L; Stainless steel
2	Back panel	60004852		UC-L; Plastic
3	Back panel	60004922		UC-XL; Stainless steel
4	Back panel	62003856		UC-M Energy; Stainless steel
4	Back panel	62003961		UC-M Energy; Plastic
5	Back panel	60004714		UC-L Energy; Stainless steel
5	Back panel	60004855		UC-L Energy; Plastic
6	Back panel	60004925		UC-XL Energy; Stainless steel
7	Base frame, rear	62003719		UC-M
8	Base frame, rear	60004402		UC-L; UC-XL
9	Cylinder head screw (Hexagon socket); M4 X 9,5	60004873	6	
10	Covering; 0,8 X 524,25 X 700,5	62003704	2	UC-M
11	Covering; 0,8 X 524,25 X 795,5	60004403	2	UC-L; UC-XL
12	Sleeve; 9,0 X D36; D20	61006576		
13	Hose nozzle; 6,25 X D15; D8,5	61004890	5	
14	Buffer; D8 X 14	40 06 023		
15	Adjustable foot; M8 X 129; SW24	60004274	4	
16	INSERT; 15,5 X 88 X 380	60004610		
17	Raised head screw; M4 X 8	20 10 310	2	
18	FOOT REST FRONT RIGHT	62003717		UC-M
19	FOOT REST FRONT RIGHT	60004593		UC-L; UC-XL
20	Floor panel; 0,8 X 517,85 X 612,28	60004617		
21	Adjustable foot; M8 X 59; SW24	62003652		
22	PT screw; KB 50 X 12	20 17 009	5	
23	TRANSVERSE GIRDER	60004532		
24	Cable gland; M25 X 1,5;9-17MM;IP68	31 10 153		
25	Hexagonal nut; M25 X 1,5 X 6,0; SW32	31 10 163		
26	FOOT RIGHT	60004531		
27	FOOT LEFT	60004530		
28	Ratchet nut; M5	21 01 310	4	
29	PT screw; KB 50 X 16	20 17 007	2	
30	FOOT REST FRONT LEFT	62003716		UC-M
31	FOOT REST FRONT LEFT	60004592		UC-L; UC-XL
32	Sheet metal screw; ST 3,9 X 13	20 20 310	10	
33	Sheet metal nut; B 3,9	21 17 301	10	
34	PT screw; KB 50 X 20	20 17 008		
35	Square nut; M8	21 08 002	2	




60005014-00

UC-M, UC-L, UC-XL

Cover plate, electrical parts


Item.	Designation	Parts no.:	Pc.	Notes
1	Cover plate	30000195		UC-x Energy
1.1	OPERATING FOIL; 0,175 X 60 X 268,5	31 24 291		
2	Cover plate	30000194		
2.1	OPERATING FOIL; 0,175 X 60 X 268,5	31 24 291		
3	Countersunk screw; M3 X 25	20 10 023	4	
4	Kit programme control Master	30000181		
5	PT screw; KB 50 X 20	20 17 008	2	
6	Support corner rear; 60 X 89 X 149,5	60004525	2	
7	Guide profile; 439,5 LG	60004526	2	
8	Ratchet nut; M5	21 01 310		
9	Support corner front right; 51,4 X 119,4 X 163,6	60004523		
10	Assembly plate; 61,1 X 223,9 X 272,4	60004522		
11	Support corner left; 36,5 X 97,2 X 163,6	60004524		
12	Kit programme control Slave	30000170		
13	Kit frequency inverter	30000121		
13.1	Heat conducting foil; 0,5 X 39 X 163 MM	60004641		
14	Washer; D4,3 X D12 X 1,0	22 05 300	2	
15	Countersunk screw; M3 X 25	20 10 023	2	
16	BUS CABLE UC-S/M/L/XL; 0,35QMM; 980 LG	60004690		
17	Contacteur B7:3H 1 N/C contact; 220-255V/50-60HZ	31 04 154		UC-x Cool



UC-M, UC-L, UC-XL

Door

Item.	Designation	Parts no.:	Pc.	Notes
2	Door seal; 463,7 X 575,9	60004475		
3	Washer; D5,3 X D15 X 1,2	22 05 301		
4	Washer; D5,3 X D10 X 1,0	22 01 300		
5	Hexagonal nut; M5 SELBSTSICHERND	21 05 302		
6	Leaf spring repair kit	60003998		
7	buffer; 7,93 X 14 X 44,2	60004950	2	
8	Sliding roller; 10,5 X 22,5 X 25	60004595	2	
9	Tension spring; L0=193;L1=360;F1=82	60003697		
10	Door cpl.	60004566		UC-M
11	Door cpl.	60004346		UC-L; UC-XL
12	Kit door handle	30000129		
12.1	Spacing piece; 14 X 33,9 X 63,3	60004685	2	
12.2	O-ring; 6 X 2	27 07 012	2	
12.3	O-ring; 5 X 1,2	27 07 070	2	
12.4	Oval head screw with hexagonal socket; M5 X 30 MIT FLANSCH	20 10 308	2	
13	Basic panel, right	60004338		
14	Basic panel, left	60004414		
15	Magnetic switch; 25,5 X D5,8;720MM LG	31 24 295		
16	Support corner front right; 51,4 X 119,4 X 163,6	60004523		
17	Ratchet nut; M5	21 01 310	2	
18	SPRING HOLDER; 1,25 X 50 X 84	60004515	2	UC-L; UC-XL
19	PT screw; KB 50 X 16	20 17 007		
20	SPRING HOLDER (M); 1,5 X 51 X 138,5	60004841		UC-M




60005016-00


UC-M, UC-L, UC-XL

Energy (Option)


Item.	Designation	Parts no.:	Pc.	Notes
1	KIT RADIAL FAN	30000189		
1.1	SEAL FAN; 51,8 X 79,4 X 2,5	60004606		
1.2	O-ring; 62,5 X 3	27 07 098		
1.3	Cable tie; 200 X 4,7	31 20 015	2	
2	Hexagon screw; M5 X 16; A70	20 01 309	4	
3	Ratchet nut; M5	21 01 310		
4	Kit HEAT EXCHANGER	30000190		
4.1	SEAL FAN; 51,8 X 79,4 X 2,5	60004606		
4.2	O-ring; 56 X 3,0	27 07 086		
4.3	Lock nut; S54 X 4; D56	60003001		
4.4	Cable tie; 200 X 4,7	31 20 015	2	
5	Wire hose clamp; D16,4 X 1,8	28 02 352		
6	Wire hose clamp; D40,5 X 3,2	28 02 365		
7	Moulded hose; DN33 X 2,0	60004517		
8	RISER WRASEN	62003778		UC-M
9	RISER WRASEN	60004510		UC-L; UC-XL
10				See page 27-28
11				See page 27-28
12	Cylindrical screw; M6 X 20	30000161	3	
13	INTAKE SOCKET WRASEN CONDENSATOR; D94 X 127	60004586		
14	O-ring; 32 X 3	27 07 082		
15				See page 27-28
16	Wire hose clamp; D17,3 X 1,8	28 02 353		




Standard




UK / Australia



Energy



Water softener




Energy / Water softener

60005017-00

UC-M, UC-L, UC-XL

Hoses

Item.	Designation	Parts no.:	Pc.	Notes
1	Moulded hose; DN10 X 3,5 X 461	60004642		
2	Moulded hose; DN10 X DN11 X 2,0	60004643		
3	Moulded hose; DN23,5 X DN26,5 X 3,5	60004573		
4	Moulded hose; DN18 X DN24 X 3,5	60004632		
5	MOLDED HOSE BOTTOM; DN13,5 X 3,0 X 370	60004625		
6	MOLDED HOSE TOP; DN13,5 X 3,0 X 605	60004644		UC-M
6	MOLDED HOSE TOP; DN13,5 X 3,0 X 700	60004624		UC-L; UC-XL
7	Moulded hose; DN13 X 2,0	60004667		
8	Moulded hose; DN10 X DN13 X 2,0	60004664		
9	Moulded hose; DN10 X DN11 X 2,0	60004670		
10	Moulded hose; DN10 X 2,0	60004684		UC-M
10	Moulded hose; DN10 X 2,0	60004673		UC-L; UC-XL
11	Moulded hose; DN13 X 2,0	60004681		UC-M
11	Moulded hose; DN13 X 2,0	60004668		UC-L; UC-XL
12	Hose; DN10 X 2,0	40 01 050		650 mm; "By-the-metre" goods
13	Hose; DN10 X 2,0	40 01 050		800 mm; "By-the-metre" goods
14	Moulded hose; DN10 X DN11 X 2,0	60004671		
15	Moulded hose; DN10 X 2,0	60004683		UC-M
15	Moulded hose; DN10 X 2,0	60004672		UC-L; UC-XL



Datum	15.05.2009	Teile-Name	Stromlaufplan
Bearb.	wbus	Zeichnungs-Nr.	89201300
Gepr.	gierera	Z-Index	01
Norm	EN 60335-2-58	ÄM-Nr.	2009 0216

Winterhalter Gastronom GmbH
Postfach 1152
D-88070 Meckenbeuren/Württ.

winterhalter

380V- 415V 3N~
220V-240V N~

Verwendung:

89201300

Blatt 1
von 1


Operating instructions



Short instructions

IMPORTANT: Read the detailed operating instructions and safety notes before first use.

Switching on the machine



- Touch the screen with your finger.
- ⇒ Screen 01 appears.



Screen 01

- Press and hold the on button (1) for approximately 2 seconds
- ⇒ Screen 02 appears.



Screen 02

The welcome message disappears automatically after a short time.




- ⇒ The machine's tank is automatically filled and heated at the same time.
- ⇒ Detergent is dosed into the machine's tank (assuming a dosing device is connected).



- ⇒ The machine is ready as soon as the rated temperatures have been reached.
- ⇒ The start button lights up green and the washing programmes are displayed¹.

Loading dishes

Starting the washing programme



- 1 Washing programmes¹
The washing programme with the white background is selected.
- 2 Start button
- 3 Self-cleaning programme

- Press the start button (2) to start the washing programme.
 - ⇒ The start button (2) first lights up in blue and then gradually turns to green to indicate the progress of the washing programme.
 - ⇒ The start button (2) flashes green as soon as the washing programme has been completed.
 - ⇒ On machines with integrated exhaust air heat recovery the start button (2) flashes green and blue whilst vapours are extracted.

Removing dishes

Switching off the machine

- Press and hold the button (3) for approximately 2 seconds to start the self-cleaning programme.
 - ⇒ The inside of the machine is cleaned and finally drained.
 - ⇒ The start button (2) lights up blue and switches off in three steps as the self-cleaning programme progresses.
 - ⇒ The machine switches off.

¹ The display of washing programmes depends on the purpose for which the machine has been programmed.

Operating instructions

for Winterhalter UC Series

1 Table of contents

1	Table of contents	1
2	About these instructions	3
2.1	Explanation of symbols used	3
3	Product description	3
4	Safety notes	5
4.1	Intended use	5
4.2	Non-intended use	5
4.3	Handling chemicals (detergent, rinse aid, descaler, etc.)	5
4.4	General safety notes	5
4.5	Daily cleaning and care	6
5	Before working with the machine	6
5.1	Checking that your delivery is complete	6
5.2	Initial installation	6
6	Rinse aid and detergent	7
6.1	Safety notes	7
6.2	Rinse aid	7
6.3	Detergent	7
6.3.1	Dosing the detergent powder	7
6.3.2	Dosing the liquid detergent	8
6.4	Venting the dosing device	8
7	Integrated water softener (optional)	9
7.1	Entering the water hardness	9
7.2	Lack of salt display	9
7.3	Adding regeneration salt	9
8	Controls	10
8.1	Touchscreen	10
8.1.1	Switching on the screen	11
8.1.2	Menu levels	11
8.1.3	Screen saver	11
8.2	Start button	12
9	Operation	13
9.1	Switching on	13
9.1.1	Before switching on the machine	13
9.1.2	Switching the machine on and preparing it so that it is ready for operation	13
9.2	Washing	14
9.2.1	The standard programmes	14
9.2.2	Loading dishes	15
9.2.3	Starting the washing programme	16
9.2.4	Completion of the programme	17
9.2.5	Completion of the programme (Version Energy)	17
9.2.6	Cancelling the washing programme prematurely	17
9.2.7	Breaks in operation	17
9.3	Switching off	17
10	Maintenance and care	18
10.1	Daily	18
10.1.1	During operation	18
10.1.2	After washing	18
10.1.3	Cleaning the inside of the machine	19
10.1.4	Cleaning the outside of the machine	21
10.1.5	Checking the external water treatment (if available)	21
10.2	Monthly	21

10.2.1	Cleaning the dirt trap -----	21
10.3	As necessary -----	21
10.3.1	Descaling -----	21
10.4	Maintenance by customer service -----	21
10.5	Changing the detergent product -----	22
11	Info level 1 -----	23
11.1	Buttons for area (1) -----	23
11.1.1	Using additional programmes -----	24
11.1.2	Additional programmes for special equipment "Cool" and "ReTemp" -----	24
12	Info level 2 -----	25
12.1	Events and malfunctions -----	25
13	Taking the machine out of service for a longer period of time -----	26
14	Malfunctions -----	27
14.1	Pictograms -----	27
14.2	Calling up the error code -----	28
14.3	Poor cleaning results -----	29
14.4	Calibrating the touchscreen -----	29
15	PIN menu -----	30
15.1	PIN menu -----	31
15.2	General settings -----	31
15.2.1	Date, time, ° Celsius / ° Fahrenheit -----	31
15.2.2	Setting the contrast -----	32
15.2.3	Setting the language -----	32
15.3	Automatic activation -----	33
15.4	Operating data -----	34
15.5	Hygiene logbook -----	34
15.5.1	Data transfer to PC (option) -----	35
15.6	Descaling / basic cleaning -----	35
15.6.1	Descaling programme -----	35
15.6.2	Basic cleaning programme -----	37
15.7	Changing the amount of detergent / rinse aid -----	38
15.8	Programming connection terminals -----	39
15.9	Resetting the countdown water meter -----	40
16	Disposal -----	41
17	Technical data -----	41
17.1	Technical data -----	41
17.2	Emissions -----	41
18	Installation -----	42
19	Water connection -----	42
20	Electrical connection -----	42
20.1	Mains connection cable -----	43
20.2	Bonding connection -----	43
21	Position of the dosing points (detergent, rinse aid) -----	44

2 About these instructions

From chapters 4 to 14, you can find information about which safety notes should be complied with, how to operate the machine and how to respond to malfunctions.

Chapters 15 to 17 tell you more about the electronic control unit and which special equipment is available. Chapter 20.1 describes where the dosing points for detergent and rinse aid are found. This chapter is intended for service technicians authorised by Winterhalter.

2.1 Explanation of symbols used

The following symbols are used:



Danger

Warning of possible severe and even fatal injuries to people if the described precautionary measures are not observed.



Warning

Warning of possible slight injuries to people or possible material damage if the described precautionary measures are not observed.



Caution

Warning of possible defects or irreparable damage to the product if the described precautionary measures are not observed.

IMPORTANT This provides important information

INFO

This provides useful information



These arrows indicate procedural instructions



This symbol indicates the results of your actions



This symbol denotes lists



This symbol refers to a chapter with further information

3 Product description

The UC series dishwashing machines are designed to be used to wash various dishes. The service technician authorised by Winterhalter does not program the machine's control unit for use of the dishwashing machine as a "special machine" for a specific application until it is installed. Alternatively, the dishwashing machine is supplied ready-programmed for a specific application, but can be reprogrammed at any time.

Programming determines whether the machine can be used either as:

- a dishwashing machine (if mostly dishes are to be washed), or as
- a glasswashing machine (if mostly glasses are to be washed), or as
- a bistro dishwashing machine (if dishes and glasses are to be washed), or as
- a cutlery rinsing machine (if only cutlery is to be washed).

If the application changes, the service technician authorised by Winterhalter reprograms the control unit and thus adapts it to your requirements.

The UC series dishwashing machines are available in the following sizes:

Machine type	Width [mm]	Depth [mm]	Height ¹ [mm]
UC-S	460	603	725-760
UC-M	600	603	725-760
UC-L	600	603	820-855
UC-XL	600	637	820-855

¹ On machines with integrated exhaust air heat recovery (Energy) the height dimension increases by 85 mm

Special equipment

Cool (only for glass washing machines)

The washing power of the constantly hot tank water ensures hygienic results. At the end of the wash cycle, the rinse with cold fresh water ensures the glasses are cooled.

The special benefit: the rinse temperature can be increased at any time. You can always at all times whether you require cold glasses or wish to optimise drying with a hot rinse.

IMPORTANT: The first wash cycles after activation of the function are performed with hot or warm rinse water.

Requirement: Machine connection to cold water.

ReTemp (only for glass washing machines)

You use this process to wash at reduced tank and boiler temperatures. Winterhalter detergent and rinse aid are specially designed for this process and are required for washing at these temperatures.

With the tank and boiler temperatures reduced, you can save energy, which also enables you to reduce your operating costs. At the same time, the air quality in the bar area is improved in the long-term since less vapour escapes from the machine when the machine door is opened. The function can be deactivated at any time.

IMPORTANT: The first wash cycles after activation of the function are performed with hot or warm rinse water.

Energy

The construction above the machine includes a fan motor and a heat exchanger. After rinsing, the fan motor draws the moist, warm vapours out of the washing area through the heat exchanger. The cold fresh water which flows through the heat exchanger for rinsing during the following washing programme condenses the vapours and is pre-heated. This reduces the energy required to heat the fresh water to the required rinse temperature. At the same time, the air quality in the kitchen is improved in the long-term since less vapour (i.e. exhaust) escapes the machine when the machine door is opened.

Requirement: Machine connection to cold water.

4 Safety notes

In order to be able to use the UC series dishwashing machine safely, carefully read the safety notes listed here.

4.1 Intended use

- The UC series dishwashing machine is to be used exclusively for washing dishes, e.g. plates, cups, cutlery and trays or for washing glasses in catering and similar companies.
- Always wash using washing racks suitable for the dishes. Never wash without a washing rack.
- The UC series dishwashing machines are technical pieces of equipment for commercial use and are not intended for domestic applications.

4.2 Non-intended use

- This device is not designed for use by persons (including children) who have a restricted physical, sensory or mental capacity, or persons who lack experience and knowledge of how to use this device. Any such persons must first be instructed by a supervisory person with responsibility for their safety, or supervised whilst operating the device.
- Do not use the dishwashing machine for washing electrically heated cooking implements or items made of wood.
- Do not wash plastic items unless they are heat-resistant and will not be damaged by the detergent solution.
- Only use a suitable detergent to wash aluminium items such as pots, containers or tins, in order to prevent black discolouration.
- Winterhalter Gastronom GmbH will not accept liability for any damage caused by failure to use the dishwashing machine in accordance with the intended use.

4.3 Handling chemicals (detergent, rinse aid, descaler, etc.)

- When using chemicals, adhere to the safety notes and recommended dosages printed on the packaging.
- Wear protective clothing, protective gloves and protective goggles when handling chemicals.
- Only use products which are suitable for commercial dishwashing machines. Such products are marked accordingly. We recommend using products developed by Winterhalter. These products are specially adapted for Winterhalter dishwashing machines.
- Do not mix different detergent products as this could result in crystallisation and consequently cause irreparable damage to the detergent dosing device.
- Do not use any foaming products, e.g. hand soap, soft soap, manual wash-up cleaner. These products must not enter the dishwashing machine, even through pre-washing of the dishes.

4.4 General safety notes

- Carefully read through the safety and operating notes contained in these instructions. Winterhalter Gastronom GmbH will not accept any liability and all warranty claims will be rendered null and void if the safety notes are not observed.
- Keep the machine documents close to hand. The service technician authorised by Winterhalter require the circuit diagram for repairs.
- For your own safety, regularly test the on-site residual-current circuit breaker (RCCB) by pressing the test button.
- The dishwashing machine must not be installed in a potentially explosive atmosphere or in areas subject to frost.
- Load sharp, pointed utensils so that they cannot injure anyone.
- Keep children away from the dishwashing machine. The inside of the machine holds a solution of detergent in hot water at about 60°C.

- Train the operating personnel in how to use the machine, and inform them of the information in the safety notes. Repeat the training at regular intervals in order to prevent accidents.
- Only use your fingers to operate the touchscreen; not sharp objects.
- Have the machine connected by qualified technicians in accordance with the locally applicable regulations (water, waste water, electrics).
- Close the on-site water stop cock after completing work.
- Switch off the on-site mains disconnecter after completing work.
- Do not open the machine door whilst it is washing. There is a risk that hot washing solution could be sprayed out. Cancel the washing programme beforehand (► 9.2.5).

4.5 Daily cleaning and care

- Follow the instructions for maintenance and care given in these operating instructions (► 10).
- Wear protective clothing and protective gloves before touching any parts which are covered with detergent solution (filters, wash fields etc.).
- Do not spray off the machine and the immediate vicinity (walls, floors) with a water hose, steam cleaner or pressure washer.
In order to prevent water from entering into the machine uncontrolledly, make sure that the machine's plinth is not flooded when cleaning the floor.
- Use a brush or a cloth - and not a pressure washer - for cleaning the interior of the machine.
- Do not use any scouring powder or abrasive cleaning agents.
- When performing daily cleaning, make sure that no foreign objects which may rust have been left in the interior of the machine. These objects can even cause "stainless steel" material to rust. Rust particles may originate from non-stainless steel dishes, cleaning aids, damaged wire racks or water pipes with no corrosion protection.
- Clean the outside of the machine using a suitable stainless steel cleaner and a soft cloth. We recommend Winterhalter Gastronom stainless steel cleaner and stainless steel polish.

5 Before working with the machine

- Have the machine installed by your service technician authorised by Winterhalter or dealer. You will find further information in chapter 18. Follow chapter 13 if the installation location is not free of frost.
- Have the machine connected by authorised technicians in accordance with the locally applicable standards and regulations (water, waste water, electrics). You will find further information in chapters 19 and 20.
- Have the machine commissioned by a service technician authorised by Winterhalter. At the same time, have yourself and your operating personnel trained in how to operate the machine.

5.1 Checking that your delivery is complete

- Use the delivery note to check that the delivery is complete and check for any transport damage.
- Immediately inform the transport company, the insurance company and the manufacturer of any damage.

5.2 Initial installation

- After the machine has been correctly connected to water and electricity, contact your Winterhalter branch or your dealer in order to request initial installation and training on how to operate the machine.

6 Rinse aid and detergent

6.1 Safety notes



Warning

When using chemicals, adhere to the safety notes and recommended dosages printed on the packaging.

Wear protective clothing, protective gloves and protective goggles when handling chemicals.



Caution

Only use products which are suitable for commercial dishwashing machines. Such products are marked accordingly. We recommend using products developed by Winterhalter. These products are specially adapted for Winterhalter dishwashing machines.

Do not mix different detergent products as this could result in crystallisation and consequently cause irreparable damage to the detergent dosing device (see ► 10.5).

Do not fill the storage tanks for rinse aid with detergent and vice versa.

Do not use any foaming products, e.g. hand soap, soft soap, manual wash-up cleaner. These products must not be allowed into the machine, even as a result of pre-treatment of the dishes.

6.2 Rinse aid

Rinse aid is required so that the water on the dishes drains off as a thin film and dries quickly after washing. Rinse aid is dosed into the machine's boiler automatically, either from a storage tank integrated in the machine or an external storage tank. The rinse aid dosing device is integrated into the machine. The dosing quantity is set by the service technician authorised by Winterhalter when the machine is installed.

INFO: The rinse aid dosing device is not part of the scope of delivery for all machines.



A display on the screen indicates when integrated storage tanks are empty (► 14.1). External storage tanks have to be fitted with a suction tube with level control if a display on the screen is required to show when the filling level drops.

6.3 Detergent

Detergent is required to remove food residue and soiling from the dishes. Detergent can be dosed in the following ways:

- manually as detergent powder.
- automatically from an integrated storage tank by an integrated detergent dosing device.
- automatically from an external storage tank by an integrated or externally fitted detergent dosing device.

INFO: The detergent dosing device is not part of the scope of delivery for all machines.

6.3.1 Dosing the detergent powder

Pre-dosage

- Add the detergent powder in the machine as soon as the start button lights up green. The machine is then ready for operation (heated up).
on the **S version**: approx. 30 g
on **version M, L and XL**: approx. 50 g
- Start a wash cycle immediately afterwards in order to mix the detergent powder with the water.
- Adhere to the instructions for dosing on the detergent packaging.

Additional dosage

- After 5 wash cycles add approx. 10-15 g of detergent powder in the machine.

6.3.2 Dosing the liquid detergent

The dosing quantity is set by the service technician authorised by Winterhalter when the machine is installed.



A display on the screen indicates when integrated storage tanks are empty (► 14.1). External storage tanks have to be fitted with a suction tube with level control if a display on the screen is required to show when the filling level drops.

6.4 Venting the dosing device

The dosing device has to be vented if air has entered into the dosing tube due to the storage tanks not being refilled quickly enough.

- For an integrated dosing device proceed as described in chapter 11.1.
- For an external dosing device refer to the equipment documentation.

7 Integrated water softener (optional)

Softening the tap water prevents the build-up of limescale in the machine and on the dishes. In order for the integrated water softener to function properly, the salt container must be filled with regeneration salt.

7.1 Entering the water hardness

When the machine is installed, the service technician authorised by Winterhalter measures the water hardness and enters the respective value.

7.2 Lack of salt display



A display on the screen (► 14.1) indicates when an empty salt container needs to be refilled. The display disappears after topping up the salt container as soon as approx. 3 wash cycles have been complete and some of the salt added has dissolved.

7.3 Adding regeneration salt



Caution

Only add regeneration salt to the salt container.

This salt should be fine-grained (max. 0.4-7 mm grain size). Salt tablets are not suitable. Do not add any chemicals, e.g. detergent or rinse aid. These will inevitably cause damage to the water softener.



Caution

After filling start a wash cycle.

After filling, immediately start a washing programme in order to rinse off any salt residue. Otherwise there is a risk of rusting in the filling area.



Open the machine door and remove the washing rack from the machine



Unlock the bottom rotating wash field



Remove the bottom rotating wash field from the machine



Open the screw cap on the salt container and fill the salt container to the brim with fresh water (only required for initial installation).



Place the funnel in the filling opening on the salt container and gradually add 3 bags of Winterhalter special salt (=1.5 kg). Remove the funnel and clean any salt residue from the filling area.



Screw the salt container tight again, keeping the cover straight. Re-install the bottom rotating wash field. Check whether the wash field rotates easily.

8 Controls



1: Touchscreen

2: Start button

8.1 Touchscreen

The screen displays the touch-sensitive buttons. Events as e. g. the end of program of operation malfunctions are indicated by a sequence of tones.

INFO: The service technician authorised by Winterhalter can switch off or activate the tone signal and the tone sequence.

By pressing these buttons you can:

- select the desired washing programme (it is started by pressing the start button)
- call up information
- make entries

The appearance (border, background) of a button indicates the button status, as follows:



Thick, white border
Dark background
Button can be pressed
(is available / can be activated)



Thick, white border
White background
Button has been pressed / activated



Thin, dotted border
Dark background
Button **cannot** be pressed
(is not available / cannot be activated)

Navigation buttons:



Scroll



Confirm an entry



Delete an entry



Back to the previous menu
Number of the menu

8.1.1 Switching on the screen



Screen 01

- Touch the screen with your finger.
 - ⇒ The screen switches on (screen 01) and switches back off after a short time (to prevent the machine being switched on inadvertently during cleaning).

INFO: You can find out about how to switch on the machine in chapter 9.

8.1.2 Menu levels

The machine's electronics are structured in 3 levels. Each screen has a number at the bottom right to facilitate understanding if there are any queries (see screen 01).

Menu level for washing personnel (► 9)

This menu level has linguistically neutral symbols to make it as easy as possible to operate the machine and train personnel.

Info level 1 with additional washing programmes and information (► 11)

Here, you can:

- read off the current tank and rinse temperatures
- read the machine type and machine number
- select additional programmes (Eco programme, short programme, quiet programme etc.)
- call up washing tips and operating instructions; vent built-in dosing devices
- switch to info level 2

Info level 2 (► 12)

Here, you can call up information:

- Date, time
- Events
- Malfunctions
- Messages indicating that the malfunction has been remedied
- switch to the PIN menu (► 15)

8.1.3 Screen saver



A screen saver appears if you do not make any screen entries for a certain length of time when the machine is switched on. The screen darkens if a further period of time elapses without any entries. Touch the screen to switch it back on.

INFO: The screen saver does not appear until the machine is filled. There is no screen saver in the PIN menu (► 15). The times for the screen saver can be changed by the service technician authorised by Winterhalter (► 17.1).

8.2 Start button

The start button lights up as soon as you switch on the machine. The different colours indicate the following:

Whilst the machine is being prepared for operation:

Change from red to green: Machine filling, heating up and ready for operation.



Whilst the washing programme is in progress:

Change from blue to green, finally flashes green: Washing programme in progress and is complete.



During the self-cleaning programme:

The start button lights up blue and switches off in 3 steps as the self-cleaning programme progresses.



9 Operation

9.1 Switching on

9.1.1 Before switching on the machine

- Open the on-site water stop cock.
- Switch on the on-site mains disconnector.
- For your own safety, test the on-site residual-current circuit breaker (RCCB) by pressing the test button.
- Open the machine door and check whether the wash fields (top and bottom) and the filters (strainer, filter cylinder) are installed.
- Close the machine door.



Warning When using chemicals, adhere to the safety notes and recommended dosages printed on the packaging.
Wear protective clothing, protective gloves and protective goggles when handling chemicals.
Do not mix different detergent products.

- Check whether there is detergent and rinse aid in the storage tanks (integrated in the machine or external). Top them up in time or replace the storage tanks so that the cleaning result will not be negatively affected.

9.1.2 Switching the machine on and preparing it so that it is ready for operation

This is where you learn how to prepare switch on and prepare the machine so that it is ready for operation. You can select to program the machine to switch on automatically at a certain time (► 15.3) and be ready for operation approximately 15 - 25 minutes later (depending on the water inlet temperature).



- Touch the screen with your finger.
- ⇒ Screen 01 appears.



Screen 01

- Press and hold the on button (1) for approx. 2 seconds.
- ⇒ Screen 02 appears with the welcome message.



Screen 02

The welcome message disappears automatically after a short time.



- ⇒ The machine's tank is automatically filled and heated at the same time.
- ⇒ Detergent is dosed into the machine's tank (assuming a dosing device is connected).



- ⇒ The machine is ready as soon as the rated temperatures have been reached.
- ⇒ The start button lights up green and the washing programmes are displayed¹.

¹ The display of washing programmes depends on the purpose for which the machine has been programmed. You will find an overview of the possible displays on pages 14 and 15.

Whilst the machine is being prepared to make it ready for operation, the light in the start button switches from red to green in 3 steps. The machine is ready for operation as soon as the start button lights up green.



INFO: The machine is supplied from the factory programmed so that a washing programme can be started as soon as the rated level in the machine's tank is reached.

If you are working according to HACCP directives, the service technician authorised by Winterhalter can programme the machine so the operating personnel cannot start a washing programme until the rated temperatures have also been reached.

9.2 Washing

9.2.1 The standard programmes

INFO: The display on your dishwashing machine may vary as the authorised service technician has a collection of screens from which he can have screens displayed which are specifically adapted to your dishes. On request the service technician can even hide programmes.

Programme 2 (button with white background) is preselected in each case and can be started by pressing the start button.

Display for glass washing machines



Arranged from left to right:

Programme 1
for fragile glasses

Programme 2
for less fragile glasses

Programme 3
for robust glasses

Display for dishwashing machines



Arranged from left to right:

Programme 1
for slightly dirty dishes

Programme 2
for normal dirty dishes

Programme 3
for very dirty dishes

Display for bistro dishwashing machines



Arranged from left to right:

Programme 1
for glasses

Programme 2
for glasses and cups

Programme 3
for plates

Display for cutlery rinsing machines



9.2.2 Loading dishes

- Adhere to the following guidelines when loading the washing rack with dishes and cutlery:
 - Remove any larger food residue.



Caution

An excessive level of soiling can clog the filter system and hamper the washing programme sequence.

- Place the plates into the rack with the top facing the front.
 - Load cups, bowls and pots with the opening facing downwards.
 - Wash the cutlery either upright in the cutlery holders or lying in a flat rack. Make sure that the dishes are not too closely packed. Soak the cutlery before you wash it.
 - Place knives and other sharp and pointed cutlery items with the handle at the top to avoid injuries.
- Adhere to the following guidelines when loading the washing rack with glasses:
 - Pour away any left-over drink (do not pour into the machine).
 - Remove any paper waste.
 - Rinse off any ash with water.
 - Load glasses with the opening facing downwards.
 - Space the glasses so that they do not touch. This prevents scratching.
 - For tall glasses, select a rack with the appropriate divisions so that the glasses are held in a stable position.




Caution

Do not wash any items with wax residue (e.g. candlesticks). The drain pump may be damaged by hardened wax.


- After pushing in the washing rack, check whether the top and bottom washing fields rotate freely.

9.2.3 Starting the washing programme



- (1) Washing programme (standard programme¹)
- (2) Start button
- (3) Switch to info level 1 (see chapter 11)
- (4) Info field for displaying malfunctions in the form of pictograms (see chapter 14.1)
- (5) Off button (does not drain the tank)
- (6) Self-cleaning programme (see chapter 10.1.2)

- Select the washing programme which best suits the level of soiling and the type of dishes. You will find an overview of available programmes in chapter 9.2.1.
- Press the button for the desired washing programme if it is not yet displayed with a white background. The selected washing programme remains saved until another programme is selected.
- Press the start button (2) to start the washing programme.
 - ⇒ The start button (2) lights up blue and then switches to green whilst the washing programme is in progress:



If the soiling is dried on particularly stubbornly, the washing programme can be intensified.

- Press the start button (2) twice quickly in succession ("double click").
 - ⇒ The "brush" symbol in the info field (4) flashes.



INFO: The intensified programme only affects the washing programme currently in progress and is then deactivated automatically.

¹ The display of washing programmes depends on the purpose for which the machine has been programmed. You will find an overview of the possible displays on pages 14 and 15.

9.2.4 Completion of the programme



The start button flashes green as soon as the washing programme has been completed.

INFO: The green flashing start button indicates that the washing programme has been completed and that the door has not yet been opened. If you find the flashing objectionable, an authorised service technician can set the machine control unit so that the start button no longer flashes green.

9.2.5 Completion of the programme (Version Energy)



After dishwashing, the warm-humid vapour is aspired off the washing compartment, and the heat energy stored in it is recovered for the next washing sequence. The start button **flashes blue / green**.

If possible, do not open the machine door during this time, in order to aspire the warm-humid vapours completely from the washing compartment. Open the machine door as soon as the start button **flashes green**.

9.2.6 Cancelling the washing programme prematurely

The following options are available for cancelling the washing programme prematurely

- Press the start button (2).
- Press the button for the selected washing programme on the screen.
- Press the off button (5) on the screen.

9.2.7 Breaks in operation

- In order to maintain the rated temperatures, do not switch the machine off during breaks.

9.3 Switching off

Switching off and draining the tank:



- Switch the machine off at the end of the working day using the self-cleaning programme (► 10.1.2).
- Then close the on-site water supply stop cock.
- Then switch off the on-site mains disconnector.

Switching off without draining the tank:



- Press the off button (5).
 - ⇒ The screen darkens and the machine is switched off. The tank remains filled, but the temperature is no longer maintained.

INFO: If the tank temperature has dropped too much until the next washing cycle, the tank is empty and will be refilled.



Warning

The machine remains live until the on-site mains disconnector is switched off.

10 Maintenance and care



Warning

Do not spray off the machine and the immediate vicinity (walls, floors) with a water hose, steam cleaner or pressure washer.

In order to prevent water from entering into the machine uncontrolledly, make sure that the machine's plinth is not flooded when cleaning the floor.

10.1 Daily

10.1.1 During operation



Warning

Wear protective clothing and protective gloves before touching any parts which are covered with detergent solution (filters, wash fields etc.)


Remove the filter cylinder, clean if necessary and re-insert it

10.1.2 After washing

The machine is equipped with a self-cleaning programme which assists you in cleaning the interior of the machine.



- Remove the washed dishes from the machine.
- Close the machine door.
- Press and hold the button (6) for approx. 2 seconds. Press the button (6) again if cancel the procedure.
 - ⇒ The background of the button (6) turns white.
 - ⇒ The start button (2) lights up blue and switches off in three steps as the self-cleaning programme progresses:



- ⇒ The inside of the machine is first washed out with detergent solution and then with hot fresh water. All the water is then pumped off.
- ⇒ The self-cleaning programme is completed as soon as the start button (2) and the screen are no longer illuminated. The machine switches off automatically.
- Close the on-site water supply stop cock.
- Switch off the on-site mains disconnecter.
- Open the door slightly into the vent position so that the inside of the machine can dry better. A special latch position in the door clasp is provided for this purpose. This is also important for long-term corrosion protection, even for stainless steel.

10.1.3 Cleaning the inside of the machine



Caution

When performing daily cleaning, make sure that no foreign objects which may rust have been left in the interior of the machine. These objects can even cause “stainless steel” material to rust. Rust particles may originate from non-stainless steel dishes, cleaning aids, damaged wire racks or water pipes with no corrosion protection.



Open the machine door and remove the washing rack from the machine



Unlock the top and bottom rotating wash fields



Remove both rotating wash fields from the machine



Remove the filter cylinder



Remove the strainer



Remove the bottom section of the filter



Attention! Make sure that the red valve rod in the suction duct of the washing solution circulation system is not a foreign body which has to be removed.

Remove any soiling from the interior of the machine with a brush or a cloth

Clean the labyrinth below the door



Clean the filter cylinder



Clean the strainer



Clean both rotating wash fields. If necessary, open the cleaning opening in the rotating wash field with a coin and rinse the rotating wash field with water.



Reinsert the bottom section of the filter



Reinsert the strainer



Reinsert the filter cylinder



Reinsert both the rotating wash fields. They are constructed identically and both can be installed either at the top or bottom. Check whether the wash fields rotate freely after installation



Do not close the machine door fully so that the inside of the machine can dry better. A special latch position in the door clasp is provided for this purpose. This is also important for long-term corrosion protection, even for stainless steel.

10.1.4 Cleaning the outside of the machine


- Clean the screen with a damp cloth.
- Clean the exterior surfaces with a stainless steel cleaner and stainless steel polish.

10.1.5 Checking the external water treatment (if available)

- Check whether sufficient regeneration salt has been added.

10.2 Monthly

10.2.1 Cleaning the dirt trap



- Close the on-site water supply stop cock.
- Clean the dirt filter in the dirt trap.

10.3 As necessary

10.3.1 Descaling

If the machine is operated with very hard water and without the appropriate water treatment, limescale can build up in the boiler, in the interior of the machine and in all lines which carry water.

Limescale deposits and the dirt and grease residue they contain represent a hygiene risk, and the limescale can cause the heating elements to fail. Therefore, it is essential to remove these deposits at regular intervals.

You should have the job of correctly descaling the boiler and all pipes which carry water carried out by a service technician authorised by Winterhalter.

You can descale the interior of the machine yourself using the descaling programme (► 15.6.1).



Warning

When using chemicals, adhere to the safety notes and recommended dosages printed on the packaging.

Wear protective clothing, protective gloves and protective goggles when handling chemicals.

10.4 Maintenance by customer service

We recommend having the machine serviced at least twice a year by a service technician authorised by Winterhalter. This service should also include having components which are subject to wear or ageing being checked and replaced as necessary.

Examples of such components:

- Water connection hose
- Dosing tubes
- Door seal

Winterhalter offers a service contract which includes this work and other services.



On the electronic control unit you can program the maintenance interval in operating hours and set the number of remaining operating hours from which point the symbol for maintenance / servicing is displayed. (► 17.1). If necessary, open the cleaning opening in the rotating wash field with a coin and rinse the rotating wash field with water.

10.5 Changing the detergent product

- Pay attention to the following when changing the detergent product:
 - Mixing different detergent products can lead to crystallisation and cause the dosing device to fail. This is the case even if the new detergent product is from the same manufacturer.
 - As a rule, a new detergent product means it is also necessary to reset the dosing device.
 - The entire system, comprising the storage tank, dosing tubes and detergent dosing device, has to be flushed with water before the new detergent is used.
- Have the necessary work carried out by the service technician authorised by Winterhalter so that you continue to achieve good washing results.

Winterhalter Gastronom GmbH will not accept any liability and all warranty claims will be rendered null and void in case of failure to comply with this instruction.

If the detergent is dosed from external storage tanks, you can flush the dosing tubes and the detergent dosing device with water yourself:

Procedure:



Warning

When using chemicals, adhere to the safety notes and recommended dosages printed on the packaging.

Wear protective clothing, protective gloves and protective goggles when handling chemicals. Do not mix different detergent products.


- Remove the suction tube from the storage tank and insert it in a container filled with fresh water.
- Flush the dosing tubes and the detergent dosing device with water by repeatedly using the “vent the dosing device” function (see ► 11.1). How frequently you do so depends on the length of the dosing tubes.
- Insert the suction tube into the storage tank with the new detergent.
- Repeatedly use the “vent the dosing device” function to replace the water in the dosing tubes with detergent.

11 Info level 1

This is how you access info level 1



- If the screen is darkened: Touch the screen.
- Press the button "i₁".
- ⇒ Screen 04 appears.



- (1) Buttons for calling up information, venting the dosing devices and selecting additional programmes
Further buttons appear when you press the scroll buttons (11)
- (2) Back button (to the standard programmes)
- (3) Start button
- (4) Switch to info level 2 (see chapter 12)
- (5) Machine number
- (6) Current tank temperature
- (7) Current rinse temperature
- (8) Machine type
- (9) Info field
- (10) Off button (does not drain the tank)
- (11) Scroll buttons for area (1)

11.1 Buttons for area (1)



Scroll down to show the following buttons



If you press this button, 2 addresses appear on the screen:

SERVICE: Address of the service technician

CHEMICALS: Address of the chemicals supplier (rinse aid, detergent etc.)

Requirement: The addresses will have been entered when the machine was installed.



If you press and hold this button, the integrated detergent dosing device is activated (max. 30 seconds). The background of the button turns white.

Use this function to vent the integrated detergent dosing device and the dosing tubes. See also chapters 6.4 and 10.5.



If you press and hold this button, the integrated rinse aid dosing device is activated (max. 30 seconds). The background of the button turns white.

Use this function to vent the integrated rinse aid dosing device and the dosing tubes. See also chapter 6.4.



If you press this button, the integrated operating instructions appear on the screen. Use these operating instructions to train your personnel, for instance.



If you press this button, tips on topics such as hygiene, protecting the dishes, cost-efficiency etc. appear on the screen.

INFO: The integrated operating instructions and tips can be called up at any time, even whilst a washing programme is in progress.



Scroll down to display the buttons for the additional programmes. The number of special programmes depends on the machine programming.



Energy-saving programme



Quiet programme
for very quiet washing in the bar area



Short programme



Special programme
The special programme can be programmed by the Winterhalter special programme freely in accordance with your requirements (time, temperature, mechanics, chemicals)

11.1.1 Using additional programmes

- Press the button for the desired additional programme.
 - ⇒ The background of the button turns white.
 - ⇒ The display in the info field alternates between temperatures display and the additional programme display.
- Press the start button (3) to start the additional programme.
 - ⇒ The start button (3) lights up blue.
 - ⇒ The start button (3) flashes green as soon as the additional programme has been completed.
 - ⇒ The additional programme remains saved until it is deactivated or another programme is selected.

11.1.2 Additional programmes for special equipment “Cool” and “ReTemp”



INFO: The button only appears on “Cool” type machines.
Rinsing is performed with cold water as long as the button is activated (white background). The button has to be pressed in order to deactivate the “Cool” function.

⇒ The background darkens and  flashes in the info field (9).



INFO: The button only appears on “ReTemp” type machines.
Washing is performed at reduced temperatures as long as the button is activated (white background). The button has to be pressed in order to deactivate the “ReTemp” function.


⇒ The background darkens and  flashes in the info field (9).

12 Info level 2

This is how you access info level 2



- If the screen is darkened: Touch the screen.
- Press the button “i₁” and then the button “i₂”
⇒ Screen 33 appears.



Screen 33

- (1) Area for displaying events and malfunctions
Further buttons and malfunctions appear when you press the scroll buttons (11)
- (2) Back button (to info level 1)
- (3) Start button
- (4) Switch to PIN menu (see chapter 15)
- (5) Time
- (6) Current tank temperature
- (7) Current rinse temperature
- (8) Date
- (9) Info field
- (10) Off button (does not drain the tank)
- (11) Scroll buttons for area (1)

12.1 Events and malfunctions

The following is displayed in area (1):

- Events
- Malfunctions
- Messages indicating that the malfunction has been remedied

Example:

Display	Explanation
Evt 01 Machine ON	Machine has been switched on
ERR 16 Rinse aid empty	No rinse aid
Evt 03 Ready	The machine is ready for operation
ERR 16 OK Rinse aid full	Rinse aid has been added
Evt 04 Programme 1	Programme 1 has been started

This information shows you what last happened on the machine.

A maximum of 3 lines of text is displayed in area (1). In the display, the last entry is shown first. Earlier entries can be shown by pressing the scroll buttons (11). You will find pieces of information with the respective date in the hygiene logbook (see chapter 15.5).

13 Taking the machine out of service for a longer period of time

Adhere to these instructions if you need to take the machine out of service for a longer period of time (annual factory closing, seasonal operation).

- Drain the machine using the self-cleaning programme (► 10.1.2).
- Clean the machine as described in point 10.1.3.
- Leave the machine door open.
- Close the on-site water supply stop cock.
- Switch off the on-site mains disconnecter.

If the machine is installed in a room which is not frost protected:

- Have the machine made frost-proof by a service technician authorised by Winterhalter.

Putting the machine back into service

- Open the on-site water stop cock.
- Switch on the on-site mains disconnecter.
- Switch on the machine.

14 Malfunctions

In this section you learn how to act in case of malfunctions. The table lists possible causes and instructions for remedial action. Contact a service technician authorised by Winterhalter if you are unable to rectify the fault yourself.



Danger


DANGER! Risk of fatal injury due to live components.

Disconnect the machine from the mains and check that machine is de-energised.

Do not open any machine covers or machine components if you require a tool to do so. Risk of electric shock.

Have all work on the electrical system performed by a service technician authorised by Winterhalter. The machine must be disconnected from the electrical mains first.

14.1 Pictograms




Malfunctions are indicated by pictograms in the info field (4). In addition, each malfunction is also stored in the hygiene logbook (► 15.5) and can be called up from info level 2 (► 12). An entry is also made in both places as soon as the malfunction is remedied.

Pictogram	Meaning	Possible cause	Remedy
	The machine door is open	Programme start with open machine door	Close machine door.
	The detergent is empty ¹		Replace the container or top up the storage tank
	The rinse aid is empty ¹		Replace the container or top up the storage tank
	Water shortage or uncontrolled water feed	The water stop cock is closed	Open the stop cock
		The dirt filter in the dirt trap is blocked	Remove and clean the dirt filter (► 10.2)
		The solenoid valve is faulty or blocked	Call a service technician authorised by Winterhalter
	The integrated water treatment is exhausted	Lack of salt	Fill the salt container with re-generation salt
	External partial demineralisation unit or full demineralisation unit exhausted		Replace the partial demineralisation unit; replace the resin in the full demineralisation unit Reset the countdown water meter (► 15.9)

¹ is only displayed if the container has a container empty indicator connected to the machine.

Pictogram	Meaning	Possible cause	Remedy
	The service interval has expired	The number of operating hours entered on the control unit has elapsed. The machine should be serviced. INFO: This function is not activated in factory.	Call a service technician authorised by Winterhalter
	Check scaling	The number of operating hours entered on the control unit has elapsed. The machine should be descaled.	Start the descaling programme (see ► 15.6.1) Switch to info level 2 to delete the pictogram in the info field without starting the descaling programme
	The bottom wash field is blocked	The lower wash field is blocked, e.g. by a piece of cutlery	Remove the blockage
	The top wash field is blocked	The top wash field is blocked, e.g. by tall dishes	Remove the blockage
	Foaming	Use of manual wash-up cleaner Large amount of protein	Drain and re-fill the machine
	The strainer is blocked	Heavily soiled strainer	Remove, clean and replace the strainer
	Energy optimisation ¹	The on-site energy optimisation system switches individual electrical loads (heating elements) off.	Wait until the on-site energy optimisation system switches off
	Malfunction with error code	Various	Call up the error code (see ► 14.2) and call a service technician authorised by Winterhalter


14.2 Calling up the error code



The  symbol in the info field (4) flashes.



- Press the button “i₁” and then the button “i₂”
⇒ Screen 33 appears



Display in area (1):

- Error code
- Error remedy

- Contact a service technician authorised by Winterhalter if you are unable to rectify the fault yourself.

Screen 33

¹ is only displayed if the machine is connected to an energy optimisation system.

14.3 Poor cleaning results

	Possible cause	Remedy
Dishes are not cleaned	Too little or no detergent dosing	Set the dosing quantity according to the information provided by the manufacturer
		Check dosing lines (kinks, breaks, etc.)
		Replace the container
	Dishes not loaded correctly	Check the dosing device
		Do not stack dishes on top of one another
		Remove the wash fields and clean the jets
	The wash field jets are blocked	Remove the wash fields and clean the jets
	Temperatures too low	Check the temperatures (► 11)
Deposits form on the dishes	Limescale deposits: water is too hard	Check the external water treatment / integrated water treatment and set it correctly Perform basic cleaning (► 15.6.2)
	Starch deposits: excessively high temperatures for the manual pre-wash (spraying)	Temperature must not exceed 30°C
Dishes are not drying automatically	Too little or no rinse aid dosing	Set the dosing quantity according to the information provided by the manufacturer
		Check dosing lines (kinks, breaks, etc.)
		Replace the container
		Check the dosing device

14.4 Calibrating the touchscreen

If pressing a button fails to trigger an action, the touch-sensitive points of the displayed button may have drifted.

REMEDY:



Screen 01



Screen 19

- Switch the machine off and touch the screen once.
- Press and hold the start button for 60 seconds.
 - ⇒ Screen 19 appears.
- Use a ballpoint pen (without the ballpoint) to touch the centre of the crosshairs and follow the further instructions given on the screen.

15 PIN menu


In the PIN menu, you can:

- make general settings (date, time, contrast, language) ► 15.2
- program the automatic activation of the machine ► 15.3
- display operating data ► 15.4
- display data (hygiene logbook) ► 15.5
- start the descaling programme or basic cleaning programme ► 15.6
- Changing the amount of detergent / rinse aid ► 15.7
- program the connection terminals for external dosing devices ► 15.8
- reset the countdown water meter¹ ► 15.9

INFO: You cannot operate the machine whilst the PIN menu is active. The start button is not lit. The machine has to be switched back on again after exiting the PIN menu.

How to access the PIN menu:

- If the machine is switched off or the screen is dark: Touch the screen.



- Press the button “i₁” and then the button “i₂”.

- Press the “PIN input” button.
⇒ Screen 06 appears



Screen 06

- Enter the PIN 1575.
⇒ Every digit entered is displayed as ★.
You can delete any incorrect digits by pressing the ← button.



- Confirm with the ✓ button
⇒ The PIN menu appears (► 15.1)



INFO: The “!” symbol appears on the screen if you enter the wrong PIN.



If an incorrect PIN is entered five times in succession, you cannot make any more entries for the next 2 minutes.

¹ not for machines with integrated water softener

15.1 PIN menu



Screen 07

After scrolling:



Date, time, contrast, language ► 15.2

Automatic activation ► 15.3

Operating data ► 15.4

Hygiene logbook ► 15.5

Descaling / basic cleaning ► 15.6

Amount of detergent / rinse aid ► 15.7

Program connection terminals ► 15.8

Reset the countdown water meter ► 15.9

15.2 General settings

15.2.1 Date, time, ° Celsius / ° Fahrenheit

INFO: The time has to be changed when the clocks are changed for summertime / wintertime.

Here, you can:



- enter the current date.
- enter the current time.
- change the time format.
- change the unit of measurement for the temperature display.

How to access the settings:

➤ Enter the PIN menu

➤ Press the button

➤ Press the button



To set the date:

- Press button (1).
- Enter the current date using the numeric keypad. Format: YYYY-MM-DD (year-month-day)
The entered date is checked to determine whether it is a valid date. Your entry will not be accepted if it is implausible.

To enter the time format:

- Select whether the time should be displayed in 24-hour or AM/PM mode.
- Press the "24h" or "AM/PM" button.

To set the time:

- Press button (2).
- Enter the current time using the numeric keypad.

To define the unit of measurement for temperature:

- Press the "°C" or "°F" button depending on which unit of measurement you wish to use for displaying temperatures.

➤ Press the back button (3) to exit the menu.

15.2.2 Setting the contrast

Here, you can:

- change the contrast to adapt the screen display to the lighting conditions in your kitchen.

How to access the settings:


- Enter the PIN menu



- Press the button



- Press the button



- Use the ↑ or ↓ button to change the setting until you can see all the data clearly on the screen.
- Confirm with the ✓ button
- Press the back button (1) to exit the menu.

15.2.3 Setting the language

Here, you can:

- set the language used for displaying texts on the screen.

How to access the settings:

- Enter the PIN menu



- Press the button



- Press the button



- Select the required language.
- Press the back button (1) to exit the menu.

15.3 Automatic activation


Here, you can:

- enter when the machine is to start filling itself and heating up automatically.
-  – enter a different time for each day of the week (weekly programme).
-  – enter a time for a certain date which is different from the weekly programme. This date takes precedence over the weekly programme.

➤ Ensure that the machine door is closed, that the customer-side mains disconnect switch is switched on, and that the water shut-off valve is opened at the moment of automatic activation.

How to program automatic activation:

➤ Enter the PIN menu



➤ Press the button




Weekly programme




- Press button (1).
- Use the scroll buttons to select the day of the week which you wish to program.
- Press the button for the day of the week which you wish to program.
⇒ The background of the button turns white.
- Enter the time for the start of automatic activation at the numeric keypad.
- Enter the times for the remaining days.
- Check whether button (1) is active (white background). Automatic activation is only active for the programmed days if this is the case.
- Press the back button (3) to save your entry.

Special day



- Press button (2).
- Enter the time and the date for the start of automatic activation at the numeric keypad.
- Check whether button (2) is activated (white background). Only then will the automatic activation start for the programmed day.
- Press the back button (3) to save your entry.

INFO: The programmed date takes precedence over the weekly programme.



INFO: Date and time of the next automatic activation are displayed when the machine is switched on. Of course the machine can be used before this point of time.


15.4 Operating data

Here, you can:

- view all operating data.

How to access the operating data:

- Enter the PIN menu



- Press the button



⇒ The screen (screen 21) with the operating data appears.

- | | |
|------------------------------|----------------------|
| – Initial start-up | Date |
| – Next service in | x hours ¹ |
| – Total operation hours | x hours |
| – Total washing cycles | x |
| – Total water consumption | x litres |
| – Op. hours/day | x hours |
| – Washing cycles/day | x |
| – Water consump./day | x litres |
| – WS remaining capacity | x litres |
| – Old master operation hours | x hours |

You can scroll up and down the list using buttons ↑ and ↓.

- Press the back button (1) to exit the menu.

15.5 Hygiene logbook

In the hygiene logbook, you can:

- call up all operating statuses, actions and malfunctions during a day in chronological order.
- call up all HACCP and hygiene-related data.

The list starts with the current date and the first event on this day. Then the subsequent events of this day are displayed and then the events from previous days. The most important operating data is summarised at the end of each day.

Together with a service technician authorised by Winterhalter, you can define which data is to be stored. On request, you can have deviations from the rated values displayed on the screen so that you can respond to malfunctions in good time.

A table with the factory settings can be found in point 17.1 Technical data.

INFO: Once the memory capacity has been exhausted, the oldest data is deleted as soon as new data is added.

¹ This function is not activated in factory.

How to call up the hygiene logbook:

- Enter the PIN menu



PIN 1575

- Press the button



⇒ The screen (screen 09) with the hygiene logbook appears:

- The list starts with the current date and the first event on this day.
- This is followed by events from the day before. You can scroll up and down the list using buttons ↑ and ↓.

- Press the back button (1) to exit the menu.

1
Screen 09

15.5.1 Data transfer to PC (option)

The hygiene logbook can only hold a limited number of entries. Therefore, it is also possible to transfer the entries to a PC and archive them there.

Refer to the respective documents for further information.

15.6 Descaling / basic cleaning**15.6.1 Descaling programme**

If the machine is operated with very hard water and without water treatment, limescale can build up in the boiler, on the interior of the machine and in all pipes which carry water.

Limescale deposits and the dirt and grease residue they contain represent a hygiene risk, and the limescale can cause the heating elements to fail. Therefore, it is essential to remove these deposits at regular intervals.

Because the quality of water affects the washing and drying performance, we recommend that you feed the machine with softened water if your water has a total hardness of more than 3°dH (0.53 mmol/l).

A service technician authorised by Winterhalter will be happy to offer advice.

Using the descaling programme you can descale the inside of the dishwashing machine. The water-carrying pipes and the boiler can only be descaled by a service technician authorised by Winterhalter.

For descaling you require an acid-based descaler which is suitable for commercial dishwashing machines. We recommend Winterhalter Descaler F.

**Warning**

When using chemicals, adhere to the safety notes and recommended dosages printed on the packaging.

Wear protective clothing, protective gloves and protective goggles when handling chemicals.

Ideally you should start the descaling programme when the machine is empty and switched off. If the machine is already ready for operation, it is first drained (programme-controlled) as chlorine gas can be generated if active chlorinated detergent and descaler are allowed to mix in the machine.

How to start the descaling programme:

If detergent is dosed using a dosing device which is installed outside the machine:


- Stop the dosing of detergents (e.g. pull out the suction tube or switch off the dosing device) in order to prevent the active chlorinated detergent coming into contact with descaler and producing chlorine gas.

INFO: An integrated detergent dosing device is deactivated in the descaling programme (programme-controlled).

- Enter the PIN menu



- Press the button
⇒ Screen 28 appears.



- Press button (1).
⇒ Button (1) flashes.
⇒ The descaling programme runs automatically.

Cancellation is possible by:

- Pressing button (28) or switching off the machine the descaling programme must be restarted.
- Opening the machine door after closing the door, the program continues automatically.



Warning

Descaler produces chemical burns

The descaling solution must not remain in the machine. If you switch off the machine when the descaling programme is in progress or if you interrupt the programme, the machine must be emptied, refilled and again emptied. Use the self-cleaning programme for this.

Descaling programme sequence:

- ⇒ If the machine is ready for operation: The tank is drained and re-filled without detergent.
- ⇒ If the machine is empty and switched off: The tank is filled without detergent.
- ⇒ As soon as the machine is ready for operation, the text “Add descaler. Press start button” appears on the screen.
- Open the door and add the descaler on the inside of the machine. Adhere to the recommended dosage.
INFO: The tank capacity is 9.5 litres (machine size S) or 15.3 litres (machine sizes M, L and XL).
- Close the door and press the start button.
⇒ The start button lights up blue. Button (1) continues to flash.
⇒ The descaler solution is circulated inside the machine.
⇒ 600 seconds are counted down on the touchscreen.
⇒ As soon as the time has elapsed, button (1) stops flashing.
- Open the door and check whether the inside of the machine has been sufficiently descaled.
INFO: If the door isn't opened for 600 seconds, the descaling program continues.
- Add descaler again if you can still see white deposits. Close the door and press the start button.
- Press the back button (28) when you can no longer see any white deposits on the inside of the machine.
⇒ The machine is drained and is then re-filled with cold water. As soon as the rated level is achieved, the cold water is circulated for 60 seconds and then drained off.
⇒ The machine switches off automatically.
- Open the door and check whether the machine has been fully drained.

15.6.2 Basic cleaning programme

New dishes or new glasses usually have a coating of soiling which can be removed using the basic cleaning programme. The programme can also be used if the dishes are coated with starchy deposits for instance.

How to start the basic cleaning programme:

- Enter the PIN menu



- Press the button
⇒ Screen 28 appears.



Screen 28

- Press button (2).
⇒ Button (2) flashes.
⇒ The basic cleaning programme runs automatically.

Cancellation is possible by:

- Pressing button (28) or switching off the machine restart of the basic cleaning programme.
- Opening the machine door after closing the door, the program continues automatically.

Basic cleaning programme sequence:

- ⇒ If the machine is empty and switched off: the tank is filled and heated up.
- ⇒ If the machine is ready for operation: A little water still flows into the boiler.
- ⇒ As soon as the machine is ready for operation, the text "Add basic detergent. Press start button" appears on the screen.
- Open the door and add the basic detergent on the inside of the machine. Adhere to the recommended dosage.
INFO: The tank capacity is 9.5 litres (machine size S) or 15.3 litres (machine sizes M, L and XL).
- Push the rack with the dishes you wish to clean into the machine.
- Close the door and press the start button.
⇒ The start button lights up blue. Button (2) continues to flash.
⇒ The detergent solution is circulated inside the machine.
⇒ 300 seconds are counted down on the screen.
⇒ A pause for drip-drying and the rinse then follow.
⇒ As soon as the basic cleaning programme is completed, button (2) stops flashing and the start button flashes green.
- Open the door and remove the dishes from the machine.
- Wash further racks or press the back button (3) to exit the menu.

15.7 Changing the amount of detergent / rinse aid



When a new detergent or a new rinse aid is used, it may be necessary to change the dosing amount. Please observe the dosing recommendations on the packing.

The dosing amount can be adjusted separately for every standard programme.

IMPORTANT! In the next menu, only the dosing amount of the installed dosing devices is changed. Please observe the corresponding device documents for external dosing devices

How to enter the menu:

- Enter the PIN menu
- Press the button
⇒ Screen 38 appears.



The screen is divided up into 3 areas:

- A: Selection of the programme which is to be changed
Selection of the process (washing or rinsing)
Saving the changed values
- B: Indication of the currently programmed values, as soon as a standard programme is selected
- C: Scroll buttons for changing values in area C




Area A:

- 1: Standard programme 1
- 2: Standard programme 2
- 3: Standard programme 3
- 4: Switch Detergent <> Rinse aid
Detergent: button with dark background
Rinse aid: button with white background
- 5: Saving the changed values

INFO: The appearance of the pictograms 1-3 depends on the type of dishwashing machine. The example shows the standard programmes of a dishwashing machine.

Example 1: The detergent dosing amount is to be increased for standard programme 1



- Press button (1).
⇒ The background of buttons (1) and (2) changes to white.
⇒ The current detergent dosing amount (3.0 ml/l) and the internal name (P003) is displayed in field (3).
- Increase the detergent dosing amount by pressing button (4).
- Press button (5) in order to save the entry.
⇒ Button (5) flashes once in white.

Example 2: The rinse aid dosing amount is to be increased for standard programme 2

- Press button (1).
 - ⇒ The background of buttons (1) and (2) changes to white.
 - ⇒ The current detergent amount (3.0 ml/l) and the internal name (P068) is displayed in field (3).



- Press button (4).
 - ⇒ The background of button (4) becomes white.
 - ⇒ The current rinse aid dosing amount (0.3 ml/l) and the internal name (P072) is displayed in field (3).



- Decrease the rinse aid dosing amount by pressing button (5).
- Press button (6) in order to save the entry.
 - ⇒ Button (6) flashes once in white.

How to leave the menu:

- Press button
- Press button
- Switch the machine on again


**15.8 Programming connection terminals**

In the dishwashing machine's plinth there is a transfer strip for connecting an external detergent dosing device (► 21).

The transfer strip can be assigned various signals depending on how parameter P704 is set. The technician who connects the detergent dosing device sets parameter P704 when installing the machine.

How to make parameter P704 accessible:

- Enter the PIN menu
- Press the button
 - ⇒ Screen 14 appears.



Screen 14

- Use the scroll buttons to set the value for parameter P704.
 - 0: Voltage to the "Wash" terminal when the circulating pump frequency inverter is active. Tension at the "Fill" terminal during the first filling of the tank.
 - 1: Voltage to the "Fill" terminal when the inlet solenoid valve is active.
 - 2: For time-controlled dosing device (e.g. SP 166Z)
 - 3: For pulse-controlled dosing device (e.g. Fluidos)

15.9 Resetting the countdown water meter

INFO: not for machines with integrated water softener



The countdown water counter has to be reset if on machines with a partial demineralisation unit or full demineralisation unit the symbol opposite flashes on the screen.

How to reset the countdown water meter:

- Enter the PIN menu



PIN 1575



- Press the button
⇒ Screen 30 appears.



Screen 30

- Press button (2) to reset the countdown water meter.
⇒ The fault message disappears.
- Press the back button (3) to exit the menu.

INFO: Use the scroll buttons (1) to set the water quantity which, once consumed, causes the pictogram above to flash.

16 Disposal

Contact your dealer so that as many of the materials contained in the machine as possible can be recycled.

17 Technical data

17.1 Technical data

Machine type	Width [mm]	Depth [mm]	Height* [mm]
UC-S	460	603	725-760
UC-M	600	603	725-760
UC-L	600	603	820-855
UC-XL	600	637	820-855

* On machines with integrated exhaust air heat recovery (Energy) the height dimension increases by 85 mm.

Voltage	see rating plate
Total connected load	see rating plate
Fusing	see rating plate
Water pressure (flow pressure)	80 – 600 kPa (100 kPa = 1 bar)
Water inlet temperature	max. 60°C UC-...-Cool: cold water UC-...-Energy: cold water

Factory settings for hygiene logbook

Event	Screen display	Stored in hygiene logbook
Rinse aid container empty	yes	yes
Detergent container empty	yes	yes
The service interval has expired	no	no

Other events are possible on request

Screen factory settings

Event	Possible selections	Factory setting
Screen saver	yes/no	yes
Screen saver appears after	0 – 63 minutes	10 minutes
Screen darkens	yes/no	yes
Screen darkens after	0 – 63 minutes	20 minutes
Acoustic signal when buttons pressed	yes/no	yes
Machine is ready for operation before rated temperatures have been reached	yes/no	yes

17.2 Emissions

Noise

The emission sound pressure level at a work station L_{pAeq} as per EN ISO 11202 is < 60 dB(A)

Exhaust air

The ventilation system must be configured in compliance with VDI Guideline 2052.

18 Installation

Instructions for the service technician authorised by Winterhalter or dealer:

- Adhere to the connection diagram.
- The location for installation must be frost-proof so that the water carrying systems do not freeze.
- Align the machine using a spirit level.
- Cancel out any unevenness of the floor using the adjustable machine legs. Placement on three feet is possible if the machine is installed below a worktop.
- When opening the machine door, water vapour escapes. This vapour may cause wood to swell. If furniture adjacent to the machine is made of wood, a steam protection kit must be installed. The same applies if the machine is installed underneath a wooden work surface.

19 Water connection

Notes for the plumber:

- Adhere to the connection diagram with specifications for water inlet temperature and water pressure.
- Connect the machine to drinking water.
- Install a **main stop cock** near to the machine, in an easily accessible position in the water supply line.
- It must not be behind the machine.
- Water safety must be ensured in compliance with EN 61770. Accordingly, the machine can be connected directly to the fresh water pipe without the intervention of any additional protection device.
- Use the supply hose and fine filter located in the dishwashing machine for the water supply. The fine filter prevents particles from the water supply from penetrating into the dishwashing machine and causing rust on the cutlery and in the dishwashing machine.
- Check that the connections do not leak. The supply hose must not be shortened or damaged. Old, pre-existing hoses must not be used again.
- Use the flexible drain pipe located in the dishwashing machine for the water drain. The drain pipe must not be shortened or damaged.
- The dishwashing machine is equipped with a drain pump. The maximum pump height can be found in the connection diagram.
- If the water hardness is more than 3°d total hardness (GH), we recommend connecting a water treatment unit upstream to prevent build-up of limescale in the machine and in order to achieve optimum cleaning and drying results. The service technician authorised by Winterhalter will be happy to offer advice.

20 Electrical connection

Notes for the electrician:



Danger

DANGER! Risk of fatal injury due to live components.

Disconnect the machine from the mains and check that machine is de-energised.

The machine and its associated ancillaries must be connected by an electrical contractor authorised by the responsible power company, in accordance with locally applicable standards and regulations.

- Adhere to the connection diagram.
- Adhere to the rating plate and circuit diagram.
- Check that all electrical protection systems are fully functional.
- Connect the machine to a protective circuit which has been installed and tested in accordance with the relevant regulations.
- The machine must be connected electrically in compliance with the data on the rating plate.
- Fuse the electrical connection of the machine as a separately fused circuit, as part of the on-site system, using slow-blowing fuses or circuit breakers, in accordance with the total connected load (see rating plate).
- The machine connection (mains connection cable) should preferably be installed as a fixed connection.
- Install a mains disconnecter as well as a residual-current circuit breaker (RCCB) in the electrical feeder in accordance with the relevant regulations. These switches must disconnect all poles and must have the stipulated contact gap. The installation location must be close to the machine and must be easily accessible.

20.1 Mains connection cable



DANGER! Risk of fatal injury due to live components!

The connecting cable may only be changed or replaced by the manufacturer, its customer service representative or a similarly qualified person. Use an H07 RN-F type cable or equivalent.

The machines of the UC series are delivered with or without mains connection cable.

Requirements to the mains connection cable


- Use a cable of the type H07 RN-F or equivalent
- Section and number of wires appropriate for voltage, fusing and overall connection value

Connection of the mains connection cable in the machine

Exemplary images for a UC-L



Remove the front cladding
UC-S: additionally remove the right side cladding



Remove the bulkhead (1) towards the electric installation compartment



Insert the mains connection cable through the backside of the machine and guide it to the connection terminals at the front


Strain relief

UC-M, UC-L, UC-XL

Tighten the screwed cable connection in the electric installation compartment

UC-S

Tighten the screwed cable connection at the backside of the machine



Connect the mains connection cable to the terminals PE to N according to the connection scheme.
Observe the connection scheme fixed at the bulkhead of the electric installation compartment.

Boiler heating element

The boiler heating element is already connected. However, jumpers must be plugged in, in order not to exceed the fusing values of the mains network.

- Please observe the connection scheme fixed at the bulkhead of the electric installation compartment.

20.2 Bonding connection

Integrate the machine and any plinths and table systems in the on-site equipotential bonding system. The connection points are labelled accordingly.

There is a screw connection point marked with the earth symbol  at the back of the machine, to which the earth lead must be connected.

21 Position of the dosing points (detergent, rinse aid)



Danger

DANGER! Risk of fatal injury due to live components.

Have the dosing devices installed and commissioned by a service technician authorised by Winterhalter.

Disconnect the machine from the mains and check that machine is de-energised.




Image of a UC-L

- 1 Detergent; transparent hose
- 2 Rinse aid (behind the back wall of the machine); blue hose
- 3 Take-over strip for the connection of external dosing devices (see also section 15.8)
- 4 Rinse aid dosing device
- 5 Detergent dosing device

INFO: The dosing devices (Pos. 4 and 5) are not included in the scope of delivery of all machines.



Image of a UC-L

- 6 Inputs for detergent and rinse aid hoses if the storage containers are located outside the machine

Winterhalter Gastronom GmbH
Commercial Dishwashing Systems

Tettmanger Strasse 72
88074 Meckenbeuren · Germany
Telephone +49 (0) 75 42 4 02-0
Telefax +49 (0) 75 42 4 02-1 87

www.winterhalter.biz
info@winterhalter.biz

