mychef.

Mychef Cook, Bake, Snack and Bakershop: Control Board Settings

When replacing the control board of Cook, Bake, Snack or Bakershop ovens, the control board must be configured so that the programming is appropriate to the type of oven.

This technical note explains the steps to follow.

1. Enter the configuration menu:

With the oven switched off, press simultaneously on the **convection + Start/stop** buttons.



2. control board configuration



Once in the configuration menu the following values have to be configured:

Type of oven

a) Press the convection key  , P0 will start flashing. Use the +/- arrows to select the value "P1".

b) Press the steam key  , the second part of the display will flash. Use the +/- arrows to select the value depending on the oven:

VALUE	MODEL
0	Cook or Bake PRO
2	Cook UP
5	Cook or Bake MASTER
6	Snack or Bakershop AIR
7	Snack or Bakershop AIR-S
8	MAX MASTER

TSC Channels

a) Press the convection key  to select the "P2" register.

b) Press the steam key  to select the appropriate parameter:
- If the oven does not have TSC, leave the value at 0.
- If the oven has TSC, set the value to 2.

Autoclean

a) Press the convection key  to select the register "P3".
b) The value of the parameter must be:

VALUE	MODEL
0	No washing
1	Siphon with pumps (recirculated)
2	Without siphon (not recirculated)

Fan configuration

a) Press the convection key to select the register "P4".
b) The value of the parameter must be:

VALUE	MODEL
0	2 speeds (UP, PRO, AIR-S)
1	With frequency inverter (MAX MASTER, MASTER GAS)
4	4 speeds (MASTER)
5	1 speed (AIR)

To confirm and exit the configuration menu, press the START/STOP button for 5 seconds. 