Dormont Quick disconnect device RESTRAINER The Quick Disconnect (QD) device enables rapid and safe disconnection of gas appliances from the gas supply to allow the appliance to be moved for cleaning etc.

DISCONNECT...







Firstly isolate the gas supply by turning the local isolation valve to the 'closed' position. Grip the outer collar of the QD coupling and, whilst holding the hose, pull back the collar to release the inserted male part.





The restrainer wire can now be disconnected to allow free movement of the appliance.

by MECHLINE

CONNECT...





Holding the QD coupling and the hose, push the hose end upwards until the QD collar clicks and engages.







It is important to RECONNECT THE RESTRAINER after reconnecting the hose to the supply. DO NOT move the appliance, with the hose connected, without the restrainer in place. Finally return the gas isolation valve to the 'opened' position.